

How a standard window is flashed with DuPont FlexWrap



1

Cut a modified "I" into building wrap. Fold side and bottom flaps into opening and secure. Cut head flap and flip up to expose frame.



2

Fit DuPont FlexWrap to provide seamless protection to all sills.



3

Place Sealant around window opening so that window flange will be in contact when installed.



4

Fit window into opening.



5

Fit DuPont FlexWrap to both vertical edges of window.



6

Fit DuPont FlexWrap to header of opening.



7

Pull building wrap back down over the DuPont FlexWrap and tape in place.



8

Apply Sealant around window on inside of frame.

How a curved or difficult shape is flashed with DuPont FlexWrap



9a



9b

Start at the bottom and shape the DuPont FlexWrap around the curve for a perfect seal without cutting the material.