



DuPont™ Dymel®

AEROSOL PROPELLANTS

Toxicity of Dymel® Propellants

Before using any of the Dymel® products, review the DuPont Material Safety Data Sheets (MSDS). They can be obtained from the DuPont Customer Service Center or your DuPont representative.

Inhalation Toxicity

The occupational exposure limit set by DuPont is referred to as the acceptable exposure limit (AEL), which is the atmospheric concentration of an airborne chemical to which nearly all workers may be exposed repeatedly, day after day, during an 8-hour day, or 40-hour week, without adverse effect. The DuPont AEL for all the Dymel® propellants is 1000 ppm, 8-hour and 12-hour time weighted average (TWA), which is the highest occupational exposure limit established by DuPont. However, even though the Dymel® propellants exhibit low toxicity, it is good industrial hygiene practice to avoid unnecessary exposure to their vapors.

Because Dymel® propellant vapors are heavier than air, they can accumulate in enclosed space, e.g., a gassing room, or in spaces situated near or below floor level, e.g., a stairwell or trench. This situation could expose personnel to high concentrations of Dymel® propellant vapors accidentally. A major hazard of these materials is suffocation because of the displacement of air from contained spaces or those below floor level.

Inhaling high concentrations of Dymel® propellant vapor will affect the central nervous system and produce an anesthetic-like effect.

Symptoms may include dizziness, a feeling of intoxication, and a loss of coordination. Continued breathing of high concentrations of Dymel® vapors may produce cardiac sensitization in some individuals or may result in unconsciousness. Inhalation of very high concentrations can cause suffocation and death.

Personnel who experience any of the initial symptoms should move to fresh air and seek medical attention immediately. Recovery occurs quickly, usually with very little aftereffect.

Cardiac Sensitization

Cardiac sensitization is an increased "sensitivity" of the heart to the body's own adrenaline brought about by exposure to high concentrations of many hydrocarbons and halocarbons. This could cause cardiac irregularities and possibly cardiac arrest. The likelihood of such heart problems increases when under physical or emotional stress. If a person experiences breathing difficult, medical treatment must be given immediately. Administer oxygen. If breathing has stopped, give artificial respiration. Do not treat overexposure to Dymel® propellants with epinephrine (adrenaline) or similar catecholamines because they increase the risk of cardiac arrhythmias and arrest.

Skin and Eye Contact

In low concentrations, Dymel® propellant vapors have little or no effect on the skin or eyes and it is unlikely they would be ingested. However, if liquid Dymel® propellants contact either skin or eyes, serious frostbite can occur. Wear protective clothing when there is a risk of exposure to liquid Dymel® propellants. When splashing is possible, always wear eye protection and a face shield.

Should liquid Dymel® propellant contact the skin, treat the affected area with lukewarm water, not cold or hot water, and get medical treatment immediately.

If a splash occurs and liquid Dymel® propellants get into the eyes, flush them with water and get medical treatment immediately. Contact lens should not be worn in situations in which liquid Dymel® propellants could enter or splash into the eyes.

Spills and Leaks

In the event of a large spill or leak, evacuate all personnel to minimize exposure to high concentrations of vapor. Personnel should wear a self-contained breathing apparatus if they must enter an area in which a spill or leak occurred. Ventilate the area using blowers or fans at floor level to circulate the air. **Caution: Do not use ordinary electric fans to ventilate areas containing flammable propellant vapors. They may produce sparks that could ignite the vapors.** Always wear a self-contained breathing apparatus when entering tanks or other confined areas where high concentrations of Dymel® vapors might exist. Use the buddy system and a lifeline.

Dymel® propellants have a slightly sweet, ethereal odor that can be difficult to detect. The best way to monitor the concentration of Dymel® vapors in air is with infrared monitoring devices. Hot wire systems may not be compatible with Dymel® 152a and 134a.

Decomposition

Dymel® 134a propellant vapors can be decomposed by hot surfaces or open flames. The same is true of Dymel® 152a and A vapors when they are present in air at concentrations below their lower explosive limit (LEL). Dymel® 134a and 152a when decomposed produce toxic and irritating hydrogen fluoride vapor. The latter is hazardous and the area should be evacuated and ventilated to prevent exposure of personnel to it. However, the irritating nature of the fumes will generally force people to leave the area well before hazardous effects can occur.

The decomposition products of Dymel® A may be hazardous depending on the conditions under which it decomposes. Accordingly, Dymel® A should not be exposed to temperatures exceeding those normally encountered during its safe handling and use as an aerosol propellant.

Anyone suffering ill effects from exposure to decomposition products should be taken to fresh air and given medical treatment immediately.

Toxicity Summaries

The following toxicity summaries for each of the Dymel® propellants are available from DuPont.

- Toxicity summary for dimethyl ether (Dymel® A): H-04236
- Toxicity summary for Dymel® 152a: H-04239
- Toxicity summary for HFC-134a (Dymel® 134a): H-47121

For further information on DuPont™ Dymel® propellants, please contact your local representative:

DuPont Fluorochemicals
CRP702-1274E
Wilmington, DE 19880-0702
Tel: (800) 969-4758

Europe

DuPont de Nemours
International S.A.
2 Chemin du Pavillon
P.O. Box 50
CH-1218 Le Grand Saconnex
Geneva, Switzerland
Tel: 41-22-717-5111

Canada

DuPont Canada, Inc.
P.O. Box 2200, Streetsville
Mississauga, Ontario
Canada L5M 2H3
Tel: (905) 821-3300

Mexico

DuPont, S.A. de C.V.
Homero 206
Col. Chapultepec Morales
C.P. 11570 Mexico, D.F.
Tel: 52-5-722-1100

South America

DuPont do Brasil S.A.
Alameda Itapicuru, 506
Alphaville 06454-080 Barueri
Sao Paulo, Brazil
Tel: 55-11-7266-8263

DuPont Argentina S.A.
Casilla Correo 1888
Correo Central
1000 Buenos Aires, Argentina
Tel: 54-1-311-8167

Pacific

DuPont Australia
P.O. Box 930
North Sydney, NSW 2060
Australia
Tel: 61-2-923-6165

Japan

Mitsui DuPont Fluorochemicals Co., Ltd
Chiyoda Honsha Bldg.
5-18, 1-Chome Sarugakucho
Chiyoda-Ku, Tokyo 101-0064, Japan
Tel: 81-3-5281-5805

Asia

DuPont Taiwan
P.O. Box 81-777
Taipei, Taiwan
Tel: 886-2-514-4400

DuPont China Limited
P.O. Box TST 98851
1122 New World Office Bldg. (East Wing)
Tsim Sha Tsui
Kowloon, Hong Kong
Tel: 852-734-5398

DuPont Thailand Ltd.
9-11 Floor, Yada Bldg.
56 Silom Road
Suriyawongse, Bankrak
Bangkok 10500
Tel: 66-2-238-0026

DuPont China Ltd.
Rm. 1704, Union Bldg.
100 Yanan Rd. East
Shanghai, PR China 200 002
Tel: 86-21-328-3738

DuPont Far East Inc.
6th Floor Bangunan Sumudra
No. 1 JLN. Kontraktor U1/14, SEK U1
Hicom-Glenmarie Industrial Park
40150 Shah Alam, Selangor Malaysia
Tel: 60-3-517-2534

DuPont Korea Inc.
4/5th Floor, Asia Tower
#726, Yeoksam-dong, Kangnam-ku
Seoul, 135-082, Korea
Tel: 82-2-721-5114

DuPont Singapore Pte Ltd.
1 Maritime Square
World Trade Centre
Singapore 0409
Tel: 65-273-2244

DuPont Far East, Philippines
8th Floor, Solid Bank Bldg.
777 Paseo de Roxas
Makati, Metro Manila
Philippines
Tel: 63-2-818-9911

DuPont Far East Inc.
7A Murray's Gate Road
Alwarpet
Madras, 600 018, India
Tel: 91-44-454-029

DuPont Far East Inc.—Pakistan
9 Khayaban-E-Shaheen
Defence Phase 5
Karachi, Pakistan
Tel: 92-21-533-350

DuPont Far East Inc.
P.O. Box 2553/Jkt
Jakarta 10001, Indonesia
Tel: 62-21-517-800

dupont.com/dymel

Copyright ©2007 DuPont or its affiliates. All rights reserved. The DuPont Oval, DuPont™, The miracles of science™, and Dymel® are registered trademarks or trademarks of E.I. du Pont de Nemours and Company or its affiliates.

NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT.

Caution: Do not use in medical applications involving permanent implantation in the human body, or contact with internal body fluids or tissues. For other medical applications, see "DuPont Medical Caution Statement," H-50102.

This information is based on data believed to be reliable, but DuPont makes no warranties, express or implied, as to its accuracy and assumes no liability arising out of its use. The data listed herein falls within the normal range of product properties but should not be used to establish specification limits or used alone as the basis of design. Because DuPont cannot anticipate or control the many different conditions under which this information and/or product may be used, it does not guarantee the usefulness of the information or the suitability of its products in any given application. Users should conduct their own tests to determine the appropriateness of the product for their particular purposes.



The miracles of science™