




Suva<sup>®</sup>

refrigerants

ART - 32

**Transport  
Properties  
of Suva<sup>®</sup> 95  
Refrigerant**

Viscosity,  
Thermal Conductivity  
and  
Heat Capacity  
for the  
Liquid and Vapor






# Transport Properties of Suva<sup>®</sup> 95 Refrigerant

## TABLE OF CONTENTS


<b>English Units</b>	<b>Page</b>
Saturated Liquid Viscosity .....	1
Saturated Liquid Thermal Conductivity .....	2
Saturated Liquid Heat Capacity .....	3
Saturated Vapor Viscosity .....	4
Vapor Viscosity at One Atmosphere .....	5
Vapor Viscosity at High Pressure .....	6
Saturated Vapor Thermal Conductivity .....	7
Vapor Thermal Conductivity at One Atmosphere .....	8
Vapor Thermal Conductivity at High Pressure .....	9
Vapor Heat Capacity .....	10
Vapor Heat Capacity Ratio .....	11
Equations for Property Estimation .....	12
<b>Metric Units</b>	
Saturated Liquid Viscosity .....	13
Saturated Liquid Thermal Conductivity .....	14
Saturated Liquid Heat Capacity .....	15
Saturated Vapor Viscosity .....	16
Vapor Viscosity at One Atmosphere .....	17
Vapor Viscosity at High Pressure .....	18
Saturated Vapor Thermal Conductivity .....	19
Vapor Thermal Conductivity at One Atmosphere .....	20
Vapor Thermal Conductivity at High Pressure .....	21
Vapor Heat Capacity .....	22
Vapor Heat Capacity Ratio .....	23
Equations for Property Estimation .....	24




# Saturated Liquid Viscosity




### Saturated Liquid Thermal Conductivity




# Saturated Liquid Heat Capacity




### Saturated Vapor Viscosity




### Vapor Viscosity at Atmospheric Pressure




# Vapor Viscosity




### Saturated Vapor Thermal Conductivity




### Vapor Thermal Conductivity at Atmospheric Pressure




# Vapor Thermal Conductivity



# Vapor Heat Capacity



# Vapor Heat Capacity Ratio



## EQUATIONS FOR PROPERTY ESTIMATION

### English Units

Curves have been fitted to the measured data to obtain the following equations for estimation of Suva® 95 properties within the ranges specified.

#### Saturated Liquid Viscosity in cP (–160 to 50°F)

$$\mu = 0.146 - 1.16E-3 T + 1.02E-6 T^2 - 2.59E-8 T^3$$

#### Saturated Liquid Thermal Conductivity in Btu/hr·ft·°F (–160 to 50°F)

$$k = 3.93E-2 - 1.72E-4 T - 9.36E-9 T^2$$

#### Saturated Liquid Heat Capacity in Btu/lb·°F (–160 to 30°F)

$$C_p = 0.353 + 1.94E-3 T + 2.02E-5 T^2 + 1.29E-7 T^3 + 3.23E-10 T^4$$

#### Saturated Vapor Viscosity in cP (–120 to 40°F)

$$\mu = 1.38E-2 + 5.31E-5 T + 5.08E-7 T^2 + 5.87E-9 T^3 + 2.46E-11 T^4$$

#### Saturated Vapor Thermal Conductivity in Btu/hr·ft·°F (–120 to 40°F)

$$k = 8.02E-3 + 6.41E-5 T + 6.14E-7 T^2 + 4.82E-9 T^3 + 1.60E-11 T^4$$

#### Vapor Viscosity at One Atmosphere in cP (–120 to 220°F)


$$\mu = 1.28E-2 + 2.78E-5 T - 2.93E-9 T^2$$

#### Vapor Thermal Conductivity at One Atmosphere in Btu/hr·ft·°F (–120 to 220°F)


$$k = 6.07E-3 + 1.88E-5 T - 3.92E-12 T^2$$

Where T = Temperature, °F


### Saturated Liquid Viscosity




### Saturated Liquid Thermal Conductivity




### Saturated Liquid Heat Capacity




### Saturated Vapor Viscosity




### Vapor Viscosity at Atmospheric Pressure




# Vapor Viscosity




### Saturated Vapor Thermal Conductivity




### Vapor Thermal Conductivity at Atmospheric Pressure




### Vapor Thermal Conductivity



# Vapor Heat Capacity



# Vapor Heat Capacity Ratio



## EQUATIONS FOR PROPERTY ESTIMATION

### Metric Units

Curves have been fitted to the measured data to obtain the following equations for estimation of Suva® 95 properties within the ranges specified.

#### Saturated Liquid Viscosity in $\mu\text{Pa}\cdot\text{s}$ (–100 to 10°C)

$$\mu = 110 - 2.11 T - 4.92\text{E-}3 T^2 - 1.52\text{E-}4 T^3$$

#### Saturated Liquid Thermal Conductivity in $\text{mW}/\text{m}\cdot\text{°C}$ (–100 to 10°C)

$$k = 58.4 - 0.546 T - 1.38\text{E-}4 T^2$$

#### Saturated Liquid Heat Capacity in $\text{J}/\text{g}\cdot\text{°C}$ (–100 to 0°C)

$$C_p = 1.91 + 3.675\text{E-}2 T + 7.94\text{E-}4 T^2 + 8.53\text{E-}6 T^3 + 3.37\text{E-}8 T^4$$

#### Saturated Vapor Viscosity in $\mu\text{Pa}\cdot\text{s}$ (–80 to 0°C)

$$\mu = 16.2 + 1.92\text{E-}1 T + 3.96\text{E-}3 T^2 + 5.26\text{E-}5 T^3 + 2.58\text{E-}7 T^4$$

#### Saturated Vapor Thermal Conductivity in $\text{mW}/\text{m}\cdot\text{°C}$ (–80 to 0°C)

$$k = 18.9 + 3.65\text{E-}1 T + 6.06\text{E-}3 T^2 + 6.06\text{E-}5 T^3 + 2.45\text{E-}7 T^4$$

#### Vapor Viscosity at One Atmosphere in $\mu\text{Pa}\cdot\text{s}$ (–80 to 100°C)

$$\mu = 13.7 + 4.96\text{E-}2 T - 9.48\text{E-}6 T^2$$

#### Vapor Thermal Conductivity at One Atmosphere in $\text{mW}/\text{m}\cdot\text{°C}$ (–80 to 100°C)

$$k = 11.5 + 5.84\text{E-}2 T + 1.15\text{E-}7 T^2$$

Where T = Temperature, °C



---

**For General Information:**

DuPont Fluorochemicals  
Wilmington, DE 19898  
(800) 235-SUVA  
In Delaware: (302) 995-2150

**For Technical Information:**

Fluorochemicals Laboratory  
Wilmington, DE 19880-0711  
(800) 582-5606  
In Delaware: (302) 999-3129

---

**Europe**

DuPont de Nemours  
International S.A.  
2 Chemin du Pavillon  
P.O. Box 50  
CH-1218 Le Grand-Saconnex  
Geneva, Switzerland  
41-22-717-5111

**Canada**

DuPont Canada, Inc.  
P.O. Box 2200, Streetsville  
Mississauga, Ontario  
Canada  
L5M 2H3  
(905) 821-3300

**Mexico**

DuPont, S.A. de C.V.  
Homero 206  
Col. Chapultepec Morales  
C.P. 11570 Mexico, D.F.  
52-5-722-1000

**South America**

DuPont do Brasil S.A.  
Alameda Itapicuru, 506  
Alphaville 06400 Barueri  
São Paulo, Brazil  
55-11-421-8509

DuPont Argentina S.A.  
Casilla Correo 1888  
Correo Central  
1000 Buenos Aires, Argentina  
54-1-311-8167

**Pacific**

DuPont Australia  
P.O. Box 930  
North Sydney, NSW 2060  
Australia  
61-2-923-6165

**Japan**

Mitsui DuPont Fluorochemicals  
Co., Ltd.  
Chiyoda Honsha Bldg.  
5-18, 1-Chome Sarugakucho  
Chiyoda-Ku, Tokyo 101 Japan  
81-3-5281-5805

**Asia**

DuPont Taiwan  
P.O. Box 81-777  
Taipei, Taiwan  
886-2-514-4400

DuPont Asia Pacific Limited  
P.O. Box TST 98851  
Tsim Sha Tsui  
Kowloon, Hong Kong  
852-734-5345

DuPont Thailand  
P.O. Box 2398  
Bangkok 10501, Thailand  
66-2-238-4361

DuPont China Ltd.  
Rm. 1704, Union Bldg.  
100 Yanan Rd. East  
Shanghai, PR China 200 002  
Phone: 86-21-328-3738  
Telex: 33448 DCLSH CN  
Fax: 86-21-320-2304

DuPont Far East Inc.  
P.O. Box 12396  
50776 Kuala Lumpur, Malaysia  
Phone: 60-3-232-3522  
Telex: (784) 30391 DUFE M  
Fax: 60-3-238-7250

DuPont Korea Ltd.  
4/5th Floor, Asia Tower  
#726, Yeoksam-dong, Kangnam-Ku  
Seoul, 135-082, Korea  
82-2-721-5114

DuPont Singapore Pte. Ltd.  
1 Maritime Square #07 01  
World Trade Centre  
Singapore 0409  
65-273-2244

DuPont Far East, Philippines  
5th Floor, Solid Bank Bldg.  
777 Paseo de Roxas  
Makati, Metro Manila  
Philippines  
63-2-818-9911

DuPont Far East Inc.  
7A Murray's Gate Road  
Alwarpet  
Madras, 600 018, India  
91-44-454-029

DuPont Far East Inc.—Pakistan  
9 Khayaban-E-Shaheen  
Defence Phase 5  
Karachi, Pakistan  
92-21-533-350

DuPont Far East Inc.  
P.O. Box 2553/Jkt  
Jakarta 10001, Indonesia  
62-21-517-800

---

The information contained herein is based on technical data and tests that we believe to be reliable and is intended for use by persons having technical skill, at their own discretion and risk. Because conditions of use are outside of DuPont control, we can assume no liability for results obtained or damages incurred through the application of the data presented.



**Suva<sup>®</sup>**  
Only by DuPont